

Stellar Focus



Bipolar Stepper Focuser Controller

Table of Contents

1	Inputs and Outputs.....	3
1.1	Power and Communication.....	3
1.2	Motor and Sensors.....	4
1.2.1	Home Switch.....	4
1.2.2	Motor.....	4
1.2.3	Temperature Probe.....	4
1.2.4	Buttons.....	5
2	ASCOM Integration.....	6
2.1	Supported Features.....	6
2.2	Driver Installation.....	7
2.3	Configuration.....	8
2.3.1	Configuration Dialog.....	8
2.3.2	Basic Controls.....	9
2.3.3	Motor Parameters.....	9
2.3.4	Homing.....	10
3	Communication.....	11
3.1	Driver.....	11
3.2	Commands.....	11
3.2.1	Request Position.....	11
3.2.2	Set Position.....	12
3.2.3	Halt.....	12
3.2.4	Enable Temperature Compensation.....	13
3.2.5	Status.....	14
3.2.6	Set Motor Parameters.....	15
3.2.7	Set Zero.....	16
3.2.8	Home Switch State.....	16
3.2.9	Set Temporary Velocity Limit.....	17
3.2.10	Measured Temperature.....	17
3.2.11	Motion Status.....	18
3.2.12	Sample Commands.....	19
4	Dimensions and Mounting.....	20

1 Inputs and Outputs

1.1 Power and Communication




Figure 1: Power and communication connections

See *Dimensions and Mounting* for mating connectors and power supply information. The status indicator flashes red and green for serial receive and transmit indication.

1.2 Motor and Sensors




Figure 2: Motor and sensor connections

See *Dimensions and Mounting* for mating connectors and pins.

1.2.1 Home Switch

Pinout, oriented as in Figure 2:

5V Supply	Switch Input	Ground
-----------	--------------	--------

Table 1: Home switch connector pinout

The 5V supply pin is capable of supplying 100mA of current at 4.5-5V. Switch Input is 5V tolerant and is active high.

1.2.2 Motor

Pinout, oriented as in Figure 2:

Phase A +	+V	Phase B +
Phase A -	+V	Phase B -

Table 2: Motor connector pinout

Phase A and B connect to bipolar motor phases with the specified polarity. +V provides access to the motor supply power rail and is unused in the bipolar configuration.

1.2.3 Temperature Probe

Pinout, oriented as in Figure 2:

Temperature Probe Sense	Ground
-------------------------	--------

Table 3: Temperature probe connector pinout

This port is calibrated to have a 10k Ω NTC thermistor connected across the pins.

1.2.4 Buttons




Figure 3: Button functions

When pushed quickly, these buttons result in a movement of one step in the indicated direction. When held, they result in continuous motor movement in the indicated direction. Releasing a button while the motor is in motion results in the motor slowing, stopping, and returning to the position that was recorded at the instant the button was released. The Reverse setting in the ASCOM driver's configuration window has no effect on the direction of these buttons.

2 ASCOM Integration

2.1 Supported Features

The controller and ASCOM driver support the following features of ASCOM platform 6.3's Focuser V2 interface.

Methods	
Action	Unsupported
CommandBlind	Unsupported
CommandBool	Unsupported
CommandString	Unsupported
Dispose	Supported
Halt	Supported. Will latch the current position when this command is received and returns to it after safely decelerating, if necessary.
Move	Supported.
SetupDialog	Supported. Displays the configuration dialog box.

Table 4: Supported ASCOM methods

Properties	
Absolute	Always returns true.
Connected	Supported. Will home on connection if configured to in the configuration dialog box.
Description	Supported
DriverInfo	Supported
DriverVersion	Supported
InterfaceVersion	Supports interface version 2.
IsMoving	Supported
Link	Supported
MaxIncrement	Returns 65535.
MaxStep	Returns 65535.
Name	Supported
Position	Supported
StepSize	Unsupported
SupportedActions	Returns an empty list since actions are unsupported
TempComp	Supported
TempCompAvailable	Always returns true.
Temperature	Supported. Returns the temperature of the connected. Throws an exception if there's an issue with the sensor.

Table 5: Supported ASCOM properties

2.2 Driver Installation

To install the ASCOM driver, simply run the driver setup file. The most current version is named “Stellar Focus Setup.exe” and can be obtained by visiting https://github.com/bdm310/StellarFocus_Driver .

2.3 Configuration

2.3.1 Configuration Dialog

All configuration is done through the ASCOM driver's setup dialog box. To access it, follow this process:

1. Open ASCOM Diagnostics.
2. Click on Choose Device and select the appropriate Choose and Connect to Device.
3. Change the Device Type to Focuser and click on Choose.
4. Pick Focuser Driver for StellarFocus from the drop down list.
5. Click on Properties to bring up the configuration window.




Figure 4: Configuration Window

All settings on this page are saved to the computer when Ok is clicked. Nothing is saved if Cancel is clicked instead. The Trace check box enables ASCOM logging.

2.3.2 Basic Controls

Communication
Comm Port: COM1 [v] [Connect]

Basic
Position: 0 [Set] [Halt]
Temp Coefficient: 0 [steps/*C Enabled] ☐

Status
Position:
Moving:
Temperature:
Home Switch:

Figure 5: Basic controls

The Comm Port drop down list allows for selection of the controller's serial port from the available ports on the system. Pressing Connect will attempt to connect to a controller on that port. If successful, the same button allows for disconnection. While connected, the status frame provides continuously updated information about the controller's status. The Basic frame provides a way to command a position, halt movement, set a temperature compensation coefficient, and enable or disable temperature compensation.


2.3.3 Motor Parameters

Motor Parameters
Max Velocity: 500 [steps/sec]
Max Acceleration: 500 [steps/sec²]
Idle Power Off: ☒ Reverse: ☐
[Write Motor Params]

Figure 6: Motor parameters

This frame provides access to motor specific parameters. Max Velocity, Max Acceleration, and Idle Power Off are stored on the controller in addition to on the computer. The controller values are only updated when Write Motor Parameters is pressed. These parameters are also loaded from the controller upon connection. Reverse simply reverses the direction of movement.

2.3.4 Homing

A screenshot of a software window titled "Homing". It contains several configuration options: "Invert Home Switch" with an unchecked checkbox, "Home In + Direction" with an unchecked checkbox, and "Home on Connect" with an unchecked checkbox. There are two buttons: "Home" and "Zero Pos". Below these, "Use Switch" is checked with a blue checkmark, and "Distance" is set to "0" in a text box. At the bottom, "Home Position" is set to "0" with the unit "steps", and "Home Velocity" is set to "250" with the unit "steps/sec".

Homing	
Invert Home Switch	<input type="checkbox"/>
Home In + Direction	<input type="checkbox"/>
Home on Connect	<input type="checkbox"/>
Use Switch	<input checked="" type="checkbox"/>
Distance	0
Home Position	0 steps
Home Velocity	250 steps/sec

Figure 7: Homing

The Homing frame provides control of the homing parameters. There are two different homing processes; one in which the controller simply moves a number of steps in the specified direction in order to force the motor against a mechanical stop and a second in which a homing switch is used to find a reference position. When Home In + Direction is checked, the first stage of each process begins by moving the motor in the positive direction. If it is not checked, the motor moves in the negative direction.

The first homing process simply moves at Home Velocity speed for Distance steps in the direction set by Home In + Direction.

The second homing process has three parts. First, the controller will move at the Home Velocity in the direction set by Home In + Direction until the switch state becomes True. Second, the controller will stop and move in the opposite direction at half of Home Velocity until the switch state becomes False. Third, the controller will step in the original direction until the switch state becomes True again. This process enables switch and motor backlash compensation as well as a short time to home.

Once either homing process is complete, the controller's position is set such that the current position becomes Home Position.

If home on connect is checked, the driver will home the motor whenever it is connected to.

3 Communication

3.1 Driver

Versions of Microsoft Windows Vista and later, Linux kernels 2.6.39 and later, and Mac OS 10.9 (Mavericks) and later should automatically find and install the correct drivers. For operating systems that do not, visit <http://www.ftdichip.com/Drivers/VCP.htm> and select the appropriate installation package for your operating system and computer architecture.

3.2 Commands

The controller accepts and responds to commands over a 115200 baud full duplex serial link with odd parity and 8 data bits. When sending a command to the controller, the first byte is a header with its lower nibble containing the command number and the upper nibble containing the total number of data bytes to be transmitted. For example, sending command number 0x06 with four data bytes would result in the first byte of the packet being 0x46. Multi-byte values follow the little endian ordering scheme.

3.2.1 Request Position

	Command	1
	Data Bytes	0

Table 6: Request position command

	Command	1
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Motor Position

Table 7: Request position response

Motor Position describes the current position of the motor in units of steps.

3.2.2 Set Position

	Command	2
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Desired Motor Position

Table 8: Set position command

	Command	2
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Set Motor Position

Table 9: Set position response

Desired Motor Position describes the position to move the motor to in units of steps. Desired Motor Position is echoed back in Set Motor Position for verification.

3.2.3 Halt

	Command	3
	Data Bytes	0

Table 10: Halt command

	Command	3
	Data Bytes	0

Table 11: Halt response

The controller will latch the position at the instant this command is received and will return to it after decelerating the motor safely. This position then becomes the desired position.

3.2.4 Enable Temperature Compensation

	Command	4
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Desired Temperature Coefficient

Table 12: Enable temperature compensation command

	Command	4
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Set Temperature Coefficient

Table 13: Enable temperature compensation response

Desired Temperature Coefficient describes the position to move the motor to in units of $\frac{10 \text{ steps}}{16^{\circ}\text{C}}$.

Desired Temperature Coefficient is echoed back in Set Temperature Coefficient for verification. Temperature compensation is disabled by setting this coefficient to zero. This coefficient is not stored on the controller and will be lost on a power cycle.

3.2.5 Status

	Command	5
	Data Bytes	0

Table 14: Status command

	Command	5
	Data Bytes	6
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Temperature Coefficient
2	Unsigned 8 bit integer	Idle Off
3	Unsigned 8 bit integer	Maximum Acceleration
4	Signed 16 bit integer	Maximum Velocity

Table 15: Status response

Temperature Coefficient is the currently programmed temperature compensation coefficient and is non-zero if temperature compensation is currently active. Idle Off is non-zero if the controller is configured to turn the motor drivers off after a period of inactivity. Maximum Acceleration represents the current maximum acceleration rate in units of $\frac{100 \text{ steps}}{\text{second}^2}$. Maximum Velocity is a representation of the current maximum velocity in units of $\frac{\text{steps}}{\text{second}}$.

3.2.6 Set Motor Parameters

	Command	6
	Data Bytes	4
Starting Data Byte Number	Data Type	Description
0	Unsigned 16 bit integer	Desired Maximum Velocity
2	Unsigned 8 bit integer	Desired Maximum Acceleration
3	Unsigned 8 bit integer	Desired Idle Off

Table 16: Set motor parameters command

	Command	6
	Data Bytes	4
Starting Data Byte Number	Data Type	Description
0	Unsigned 16 bit integer	Desired Maximum Velocity
2	Unsigned 8 bit integer	Desired Maximum Acceleration
3	Unsigned 8 bit integer	Desired Idle Off

Table 17: Set motor parameters response

Desired Maximum Velocity represents of the desired maximum motor velocity in units of $\frac{steps}{second}$.

The maximum velocity value is limited to $2000 \frac{steps}{second}$. Desired Maximum Acceleration represents the desired maximum acceleration rate in units of $\frac{100 steps}{second^2}$. The maximum acceleration is limited to $127 \frac{100 steps}{second^2}$, or $12700 \frac{steps}{second^2}$. Desired Idle Off is non-zero to configure the controller to turn the motor drivers off after a period of inactivity. The controller will respond with all of the received values for verification.

3.2.7 Set Zero

	Command	2
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Desired Zero Position

Table 18: Set zero command

	Command	2
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Signed 16 bit integer	Set Zero Position

Table 19: Set zero response

The controller will reset the motor position and position set point values to the value in Desired Zero Position.

3.2.8 Home Switch State

	Command	8
	Data Bytes	0

Table 20: Home switch state command

	Command	8
	Data Bytes	1
Starting Data Byte Number	Data Type	Description
0	Unsigned 8 bit integer	Switch State

Table 21: Home switch state response

The controller will return the state of the home switch pin; 1 for a high level and 0 for a low level.

3.2.9 Set Temporary Velocity Limit

	Command	9
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Unsigned 16 bit integer	Desired Velocity Limit

Table 22: Set temporary velocity command

	Command	9
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Unsigned 16 bit integer	Set Velocity Limit

Table 23: Set temporary velocity response

Sets a temporary velocity limit in units of $\frac{\text{steps}}{\text{second}}$. This limit is not persistent and will be lost on a power cycle.

3.2.10 Measured Temperature

	Command	10
	Data Bytes	0

Table 24: Measured temperature command

	Command	10
	Data Bytes	2
Starting Data Byte Number	Data Type	Description
0	Unsigned 16 bit integer	Measured Temperature

Table 25: Measured temperature response

Measured Temperature contains the temperature of an attached probe with units of $\frac{^{\circ}\text{C}}{10}$.

3.2.11 Motion Status

	Command	11
	Data Bytes	0

Table 26: Motion status command

	Command	11
	Data Bytes	1
Starting Data Byte Number	Data Type	Description
0	Unsigned 8 bit integer	Motion Status

Table 27: Motion status response

Motion Status is non-zero if the motor is currently in motion.

3.2.12 Sample Commands

Sample command sequence to set the velocity limit to $418 \frac{\text{steps}}{\text{second}}$, the acceleration limit to $200 \frac{\text{steps}}{\text{second}^2}$ and to enable the idle power down with command 6:

Value	0x4	6	0xA2	0x01	0x02	0x01
Byte Number	0		1	2	3	4
Data Byte	-		0	1	2	3
Description	Data Bytes	Command	Velocity		Accel	IdleOff

Table 28: Sample velocity limit command

The response will be the same as the command and should be verified to ensure correct reception of the command.

Sample command sequence to request the current position with command 1:

Value	0x0	1
Byte Number	0	
Data Byte	-	
Description	Data Bytes	Command

Table 29: Sample position request command

Response to the above command showing a position of 1540 steps:

Value	0x3	1	0x04	0x06
Byte Number	0		1	2
Data Byte	-		0	1
Description	Data Bytes	Command	Motor Position	

Table 30: Sample position request response

4 Dimensions and Mounting




Figure 8: Dimensions and mounting